

PU Spray Adhesive

To create a bond, the parts to be glued together need to be clean and free of grease. A thin layer of adhesive is then applied evenly to both parts. Allow the adhesive to harden (approx. 1 minute) and join the two parts. If light pressure is applied, the adhesive then sets in a matter of seconds. Subsequent correction is not very easy, and we therefore recommend taking great care when joining items. Applying the adhesive on one side only assist an easy separation at a later point in time.

PU Adhesive (aerosol spray)



The PU Adhesive (aerosol spray, **Art. No.: E 6 3 205**) is a high-quality contact adhesive, which sets in a very short time when light pressure is applied. It has been specially developed for bonding most types of foam. It is also possible to join fabric, leather and metal.

Thinner



The thinner (**Art. No.: E 6 3 010**) can be used to remove surplus adhesive. Please note that discolouration or dissolution may occur on different surfaces, such as plastic. Always test before using.